

Panasonic

Operating Instructions

Colour Television

TX-28X1DP

TX-25X1DP

(U.K. Standard)



DOLBY SURROUND

PRO • LOGIC

"Dolby", "Pro Logic", and the  symbol are trademarks of Dolby Laboratories Licensing Corporation.
Manufactured under license from Dolby Laboratories Licensing Corporation.

QRAFN840


Please read these instructions
completely before operating this
set and retain them for future reference.

Dear Panasonic Customer

Welcome to the Panasonic family of customers. We hope that you have many years of enjoyment from your new colour television. This is a very sophisticated TV; the best way to understand the features is to read this book thoroughly, before operating the set.

How to use these Operating Instructions

These Operating Instructions are laid out as shown below, please study the layout before proceeding any further.



Contents

Preparation

Warnings and Precautions	2
Features of this TV	3
Accessories	3
Battery Installation and Replacement	4
Aerial Connection	5

Tuning Procedure

Switching the TV on / off	6
Tuning—in the channels	6

General Operation

Basic functions	7
Sound control functions	8
Video control functions	9

Dolby Pro Logic Operation

What Is Dolby Pro Logic Surround Sound	13
Setting up for Pro Logic Operation	14
Speaker setup Operation	15
Dolby Pro Logic Operation	16
Simulated mode Operation	17

General Operation

Teletext Operation	18
VCR Operation	22

Audio / Video (A/V) Connections

AV1 / AV2 21 pin terminals	24
AV3 S-Video 4 pin terminal	24
AV2 RCA Audio Out terminals	24
AV3 Video and Audio (RCA) terminals	25
Headphones	25


Reference Information

Trouble-shooting	26
Specifications	27
General Information	27


Warnings and Precautions



This TV set is designed to operate on A.C. 220V-240V, 50Hz.



To prevent damage which might result in electric shock or fire, do not expose this TV set to rain or excessive moisture.




WARNING: HIGH VOLTAGE !!!


Do not remove the rear cover as live parts are accessible when it is removed. There are no user serviceable parts inside.



Avoid exposing the TV set to direct sunlight and other sources of heat.



Remove the mains plug from the wall socket when the TV set is not used for a prolonged period of time.




CABINET AND PICTURE TUBE CARE

Remove the mains plug from the wall socket. The cabinet and picture tube can be cleaned with a soft cloth moistened with mild detergent and water. Do not use solutions containing benzol or petroleum. TV sets can produce static electricity, care must be taken whenever touching the TV screen.

SPEAKER GRILLE CARE

Remove dust with a vacuum cleaner after attaching a brush adaptor. Do not let the vacuum cleaner pipe come into direct contact with the speaker (without the adaptor). Do not use any cleaning fluids or liquids on the speaker grilles. Care must be taken with the speaker grilles as they are easily pierced by sharp objects.



Adequate ventilation is essential to prevent failure of electrical components.

FOR YOUR SAFETY PLEASE READ THE FOLLOWING TEXT CAREFULLY

This appliance is supplied with a fitted three pin mains plug for your safety and convenience. A 5 amp fuse is fitted in this plug. If the fuse is replaced then the replacement fuse must be 5 amp rated and should be approved by ASTA or BSI to BS1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the fitted plug has a removable fuse cover you must ensure that it is refitted when the fuse is replaced. If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

Replacement fuse covers can be purchased through your local Panasonic dealer.

If the fitted plug is unsuitable for the socket outlet in your home then the fuse should be removed and the plug cut off and disposed of safely. There is danger of severe electrical shock if the cut off plug is inserted into any 13 amp socket.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician.


How to replace the fuse (for plug type shown in example 1) :

Lift open the fuse compartment, in the mains plug, with a screwdriver, and replace the fuse, then press the fuse cover down securely. (See example 1).


How to replace the fuse (for plug type shown in example 2) :

Lift out the removable fuse compartment with a screwdriver and replace the fuse, then refit securely into the mains plug (See example 2).

Example 1.



Example 2.



IMPORTANT :- The wires in the mains lead of this appliance are coloured in accordance with the following code :-

BLUE : NEUTRAL

BROWN : LIVE

As the colours of the wires in the mains lead of this appliance may not correspond to the markings identifying the terminals in your plug, proceed as follows :-

1. The **BLUE** wire must be connected to the terminal marked 'N' or coloured black.
2. The **BROWN** wire must be connected to the terminal marked 'L' or coloured red.

IMPORTANT NOTE : Under no circumstances should either of these wires be connected to the Earth terminal of the three pin plug, marked with the letter 'E' or the earth symbol.

Features

Dolby Pro Logic Surround


AV In / Out (Rear)

AV In (Front)




NICAM Stereo Sound System

S-Video Input




FASTEXT Teletext

**Multi-function Remote Control
(TV / Teletext / VCR (Panasonic))**




On Screen Displays

**51 Position Tuning System
(1 - 50 plus VCR)**




Accessories

Check and identify the supplied accessories before setting up this T.V. set.




TV Stand
TX-28X1DP - TS2730
TX-25X1DP - TS2720
(Assembly Instructions are included in stand packaging)



**Remote Control Transmitter
(TNQ8E0454)**

Batteries for the Remote Control Transmitter.
(2 x R6 (UM3) size)




External Speakers Package (TS-100DP)
Consisting of :
2 x Front Speakers
2 x 5 metre Speaker Cables for the Front Speakers
2 x Rear Speakers
2 x 12 metre Speaker Cables for the Rear Speakers



Battery Installation and Replacement


Batteries : Use two R6 (UM3) dry cells (supplied).

A




Remove the remote control battery compartment lid by prising it upwards.

B



Insert the batteries correctly observing the polarities (+) and (-).

C



Replace the cover.

Important Note


If experiencing any remote control malfunctions or reduction in operating distance please check and replace batteries and clean indicator window.

Precautions

1. Do not use an old battery with a new one.
2. Ensure the batteries are inserted with the correct polarity.
3. Do not use rechargeable (Ni-Cad) batteries.
4. Do not mix battery types, i.e. Alkaline and Manganese.
5. Remove flat batteries and dispose of them immediately.

Operating Switch

Operating Switch




If any difficulty is encountered when using this remote control with Panasonic video tape recorders please check the operation of the video recorder with the operating switch set at position one and again with the switch set at position two.

Aerial Connection


Connecting the aerial

Connect your Aerial to the RF IN socket at the rear of the TV.



Connecting the aerial via a Video Recorder

Connect your Aerial to the RF IN socket at the rear of the VCR. Connect an RF coaxial cable between the VCR RF OUT socket and the TV RF IN socket.




Note : For information on how to connect a VCR to this TV using Audio / Video cables refer to pages 24 and 25.

Tuning Operation


Switching the TV on / off

To switch ON or OFF press the Power on / off button on the front of the TV.

If the power to this TV is interrupted whilst it is switched on, when power is returned the TV will automatically switch back on.




Tuning-In the channels



If the local channel numbers are known proceed to step B. Press SEARCH up or down buttons until the desired channel is on screen.

Now proceed to step C.


Note : If the channel received has a weak signal, it is advisable to continue tuning until a stronger signal is received.



Press programme up/down to select the programme position on which to store the channel.

Note :

When tuning the TV into a VCR, position '0' should be selected.



Only use this step if the local channel numbers are known.

Press the 'C' key, on the remote control.

Input the channel number as two digits using the numeric keys within six seconds. (e.g. for channel 25 press 2 and 5).

The screen will display the channel.




Press the STORE button to store the channel.

The display will flash.

Repeat steps A - D to store other channels if desired.

Operation of Controls

Standby mode




Press to switch the TV. off for a period of time.


To switch back on perform one of the following :

1. Press Standby again.
2. Select a programme position from 0 – 9 on the remote control.
3. Press programme Up / Down on the TV.

Note : If the TV. is in Standby mode it is not possible to switch it back on using the Power switch (located at the front of the TV).




Programme Position Selection



Press to change programme position by one.

OR




To select a programme between 0 – 9 press numeric key once.

To select a programme position between 10 – 50 press the --/-- key followed by the numbers required.

Direct Channel Access

If the local channel numbers are known, they may be accessed directly using the following method.




Press the 'C' key.

Press the numeric keys within five seconds. (e.g. for channel 5 press 0 and 5).

The screen will display the channel.


Note : The channel is not memorised unless STORE is pressed.



Operation of Controls


Note: Certain functions will display a coloured bar on screen for a short period of time.

Normalisation Store




Adjust the Volume, Colour, Brightness, Contrast and Sharpness to desired viewing levels. Press N-STORE to store these levels in memory.

Normalisation





Press to recall the levels previously set with Normalisation Store. The normalisation key has no effect when in the Dolby Surround sound menu system.

Sound Mute



Press to mute or restore the sound. Displayed as a red bar.


Off Timer



Press to select the required Off Time of 30, 60 or 90 minutes. The selected time will be displayed in the bottom right of the screen. To cancel press until the screen shows '0'.


Sound Control Functions (A)

Volume




Press + or - to adjust. Displayed as a green bar.

Bass




Press to select. Press + or - to adjust. Displayed as a green bar scale. **Note :** Not displayed or alterable when in 2 channel Stereo speech operation.

Treble




Press to select. Press + or - to adjust. Displayed as a green bar scale. **Note :** Not displayed or alterable when in 2 channel Stereo speech operation.

Balance



Press to select. Press + or - to adjust. Displayed as a green bar. **Note :** Not displayed or alterable when in Surround operation.

Sound Selection Sequence (A) - Remote Control Operation




Operation of Controls

Note: Certain functions will display a coloured bar on screen for a short period of time.


Video Control Functions (V)

Colour




Press to select.
Press + or - to adjust.
Displayed as a red bar.

Brightness




Press to select.
Press + or - to adjust.
Displayed as a white bar.

Contrast




Press to select.
Press + or - to adjust.
Displayed as a cyan bar.

Sharpness






Press to select.
Press + or - to adjust.
Displayed as a green bar.

Video Selection Sequence (V) – Remote Control Operation





Combined Selection Sequence (F) – TV Operation



Operation of Controls

Status / Programme Table



A



Press to display the time, channel number, programme position, Audio system and Teletext, if transmitted. The programme position and Audio system will remain on screen, press Status again to remove.

When in the Surround sound menu system, pressing the Status key changes the background to Blue from the TV picture and vice-versa.

B



Press the RED or GREEN keys to show the Programme Tables. The programme and channels will be displayed. Press STATUS to return to TV mode.

Surround On / Off

3



Press to switch between 2 channel Stereo and the last selected surround sound mode. The screen will display the option set for three seconds at the bottom of the screen.

Music / Speech

(Only when in 2 channel stereo operation)

The sound can be improved during Music or Speech mode by selecting the appropriate function.

4



Press Music / Speech to select appropriate function. Displayed on screen for a short period of time.

NICAM Stereo Sound System (2 channel Stereo operation)

(Only when receiving NICAM sound transmissions)

NICAM is a 2 channel sound broadcast system which provides either a high quality stereo soundtrack or two independent Mono soundtracks.

5

0/1



NICAM Stereo transmissions

Press to switch between NICAM Stereo and FM Mono sound output.

The screen will display the following :

Sound Output	Screen Display
NICAM Stereo	0/1
FM Mono	1/0

NICAM Mono transmissions

Press to switch between NICAM Mono I, NICAM Mono II and FM Mono.

The screen will display the following :

Sound Output	Screen Display
NICAM Mono I	I
NICAM Mono II	II
FM Mono	▽

Notes :

1. The sound outputs available are dependant upon what is transmitted on the received channel.
2. When the power is switched on, the mode is pre-set to the last memorised position.
3. If the receiving conditions deteriorate, it is advisable to switch to FM Mono mode.
4. When NICAM transmissions are not being received, the sound will be FM Mono only and there will be no screen display or selection functions.

Sleep Feature

If the set is not switched off when the TV station stops transmitting at the end of the evening, it will automatically go to standby mode after 30 minutes. This function will not operate when the TV is in AV mode.

Operation of Controls


TV / AV Selection

AV (Audio / Video) is a dedicated input and output for VCR's, Satellite receivers and other Audio / Video equipment.

Use this step for remote control operation



Press TV / AV key to switch to AV mode.




Press RED key to select AV1.

Press GREEN key to select AV2.

Press YELLOW key to select AV3.

Press TV/AV key to return to TV mode.


Use this step for TV operation




Press to rotate through AV1, AV2, AV3, and TV mode.

Notes:

1. Connecting a VCR to the AV1 or AV2 21 pin terminals will automatically switch the TV to AV mode when play is selected. If AV1 and AV2 are connected simultaneously, AV1 will have priority over AV2.
2. When connecting a S-Video VCR to the AV2 21 pin terminal, the S-Video switch at the rear of the TV must be in the down position, ensuring correct display of the picture.
3. If two S-Video inputs are connected via the AV2 21 pin terminal and the AV3 4 pin terminal, the AV2 input will be displayed on screen, AV3 must be selected manually to appear on screen.
4. The AV2 21 pin terminal is equipped with constant 'Monitor Out'. This means that the output from the AV2 21 pin terminal will be whatever is displayed on the screen e.g. tape playback from another source, AV1.
5. Examples of Audio / Video connections are shown on pages 24 / 25.



7




Operation of Controls


Picture Format Selection (Aspect)

When receiving a 16:9 format signal select to obtain the correct picture height on screen.

16 : 9 Wide screen picture viewing
4 : 3 Normal picture viewing



Press STATUS.



Press YELLOW to select 4:3 aspect ratio.


Press BLUE to select 16:9 aspect ratio.

Note : Picture format cannot be changed whilst in Teletext mode.

Last Position Memory

Certain functions have a last position memory, i.e. the setting at the time of switch off will be the setting used when the receiver is switched on again:—

Programme
AV Position
Volume
Stereo mode
Bass
Treble
Balance
Colour
Brightness
Contrast
Sharpness
Standby
Music / Speech
Audio mode (Dolby surround)



Dolby Pro Logic Operation

Shipping Condition

This TV is preset initially to 2 channel Stereo, with the Pro Logic switch at the rear set to Phantom operation. It is recommended to connect all the speakers as described on page 14 and switch to Pro Logic mode as soon as possible to benefit from the full spatial capabilities of this system.

What is Dolby Surround Pro Logic ?

For over a decade, from Star Wars to Dances with Wolves, Dolby Stereo has delighted cinema audiences with multi-dimensional sound. Dolby Stereo goes beyond mere two channel stereo, so in addition to the left and right audio channels, a centre channel and rear channel are used.

The centre channel is used to sharpen sound perspective and dialogue clarity while the rear channel is used to immerse the audience in ambience and special effects.

When Dolby stereo soundtracks are made, four channels of sound are combined into two audio tracks like conventional stereo. When movies are copied onto video tape, the (encoded) sound tracks are also copied.

There are however two types of Dolby Surround decoder, one is a Dolby Surround decoder and the other a Dolby Pro Logic decoder. The Dolby Pro Logic decoder does however generate clearer positioning of sounds and provides a full effect over a wider area of listening room. This T.V. set incorporates a Dolby Pro Logic decoder.

As well as the many film titles already available on video, there are now an increasing number of programmes being produced for television in Dolby Surround. These range from sports, dramas, talk shows and now even commercials.

Note : To use Dolby Surround Pro Logic when receiving television programmes that have been produced with the Dolby Surround information, you must be able to receive NICAM Stereo transmissions, if NICAM Stereo transmissions are not transmitted in your area then the Dolby Surround information will not be present and it will not be possible to use Pro Logic operation.

With Pro Logic, there are three modes of operation :

- 1. Normal mode**
The Centre channel (speakers built into the TV set) is used to localise precisely on screen sounds such as dialogue utilising the full benefits of Pro Logic operation.
- 2. Cinema mode**
As normal mode but with simulation added to the surround channel, to reproduce the effect of being in a cinema.
- 3. Three channel mode**
If the rear surround speakers are not connected, it is desirable to use this mode. The TV's speakers are used as the centre channel speaker and the left and right front surround speakers are used. The result is stereo Pro Logic Surround sound effect but without the rear surround speakers.

What is Phantom mode ?

Phantom mode enables full stereo sound to be heard from the internal TV speakers until such time as the external speakers are connected, the centre channel signal is re-distributed to the left and right channels and the centre internal speakers (built into the TV set) are then used to output the left and right phantom mode sound. When the external speakers are connected the rear speakers are fed with the surround signal.

What are Simulated modes ?

Simulated allows various types of surround effects to be produced by mimicking both the direct sound as heard by the audience and the sound reflected back from the surrounding walls, ceiling and floor in a space such as a Disco or five other performance areas.

Setting	Effect	Appropriate sources
Disco	A room so full of music that it seems to engulf the listener.	Disco, Dance or Jazz music.
Drama	A movie theatre filled with a rich, warm sound.	TV programmes or movies with stereo sound.
Movie	Playback of software (films) not encoded with Dolby surround.	All movies or music software recorded without Dolby surround.
Church	A church hall or arena.	Classical, Rock, Pop or Folk music. Ideal for TV programmes or music video tapes.
Stadium	A large sports stadium packed for a live game.	Any live sports occasion.
Cosmos	An echo surround effect.	Video games.

What is Stereo mode ?

In this mode normal two channel stereo operation is achieved, basic left and right audio output, this is the setting of the Television's Audio modes initially. Refer to NICAM Stereo Sound System explanation on page 10.

Dolby Pro Logic Operation


Pro Logic / Phantom switch

At the rear of the T.V. is located a switch for changing between Phantom mode and Pro Logic operation, the initial setting of this switch is for Phantom operation. When the surround speakers are connected to be used for normal Pro Logic operation, this switch must be moved across to the Pro Logic setting.


Speakers and cables

There are four external speakers provided, two for the front and two for the rear, identification between the two is provided by the label at the back of each speaker. The front speakers are two-way whilst the rear are one-way. Four cables are supplied for connecting the speakers to the terminals at the rear of the T.V. set.

Suggested placement of Surround speakers



Connection of Speakers and cables





Dolby Pro Logic Operation



Note : In Stereo (two channel or headphones) operation It is not possible to select the Speaker Set-up options.

Speaker Output Levels



The audio output levels from the different channel options e.g Left, Right, Centre and Rear, should be altered to suit the listening position. Ensure that you are at the ideal or usual listening position before altering the Speaker Output levels or Speaker Distances.



Press the MENU key, the SURROUND MODES menu will be displayed.





Press YELLOW (SETUP), the SPEAKER SETUP Menu will be displayed.



Press GREEN (F1), the SPEAKER LEVELS Menu will be displayed.

With the Pro Logic switch at the rear set to Phantom mode and with Pro Logic – Phantom or Cinema selected , only the Left, Right and Rear channels are displayed and alterable.



When in Pro Logic three channel operation only the Left, Right and Centre channels are displayed and alterable.





Press the Volume Up key to set the test signal to a comfortable listening level.

OR

Press the BLUE key to listen to the audio of the currently selected programme.





Either press RED (SELECT) to move the red box to the required channel or wait for it to automatically rotate through the channels.



When the red box is on the required channel, press the GREEN (-) or YELLOW (+) to adjust the sound level as required.


Note : If the volume level was increased to a higher setting, it is advisable to reduce it before exiting the SPEAKER LEVELS Menu.



Press BLUE (EXIT) to return to TV operation.

OR

Press the MENU key to return to the SPEAKER SETUP Menu.



Dolby Pro Logic Operation








Speaker Distance

The distance from the listening position to the Left / Right / Centre and Rear surround speakers is set using the Speaker Distance Menu.

If the distances are not correctly set and the rear surround speakers are nearer to you than the centre (Internal) speakers, you may hear "leakage" of the dialogue from the rear surround speakers.




To prevent this, the speaker distance menu allows a delaying of the signal to the surround channel, making them seem further away than they actually are, so allowing the dialogue from the centre (Internal) speakers to be heard first.

Note : In Pro Logic 3 channel operation the Speaker Distance's are not selectable, only the Left / Right and Centre speakers are used.



Dolby Pro Logic Operation



Use Pro Logic operation for videos, laser discs and television programmes bearing the Dolby Surround logo :



With Pro Logic switch at rear set to Pro Logic setting. Press GREEN (SELECT) key to select NORMAL, CINEMA or 3 CHANNEL operation.

For 3 channel operation the front external speakers should be placed at a minimum distance away from the viewing screen of the television as shown in the following diagram.

Dolby Pro-Logic Operation




Press BLUE (EXIT) to return to TV operation.

OR


The Menu will automatically disappear after ten seconds.

Simulated Mode Operation


Provides six sound effects that can be used to reproduce the different atmosphere of each one.




Press the MENU key to display the SURROUND MODES menu.



Press RED (MODE) key to select SIMULATED.




Press GREEN (SELECT) key to select the required effect from : Disco, Drama, Movie, Church, Stadium or Cosmos.



Press BLUE (EXIT) to return to TV operation.

OR

The Menu will automatically disappear after ten seconds.




Teletext Operation

Introduction

Teletext is the broadcasting of pages of information on your T.V. screen containing such subjects as News, Sport, Weather, Travel and T.V. guides. All Teletext features are operated via the Remote Control.

1. Teletext is only available if the channel selected is transmitting Teletext.
2. Teletext features may vary depending on the Broadcasting Companies.

TV / Teletext mode




Press the TV/TXT key.
The screen will display a Teletext page.
Press again when you wish to return to TV. mode.

Hold



Press to hold the current page.
Press again to cancel the hold.


Page Selection



Pages can be selected in two ways :


- a. Press the Up / Down keys to increase or decrease the page number by one.
- b. By entering the page number, using 0 – 9 on the remote control.

Reveal




Press to reveal hidden words e.g. quiz page answers.
Press again to hide.

Full / Top / Bottom



Press to expand the TOP half of the page.
Press again to expand the BOTTOM half.
Press again to return to normal (FULL) size.

Red / Green / Yellow / Blue keys



In FASTEXT mode these correspond to the differently coloured subjects.
In LIST mode they correspond to the differently coloured page numbers.

List / F.text



Press to change from FASTEXT mode to LIST mode and vice versa.

In FASTEXT mode four differently coloured subjects are displayed at the bottom of the page. Press the appropriate coloured key to access more information about one of these subjects.

List Store




In LIST mode the four page numbers can be altered for channel positions 1 – 10 only.

To do this, press one of the coloured keys and enter the new page number.

Press and hold List Store, the page numbers will change colour.

Favourite Page (F.P.)




This feature will store a favourite page number in the TV memory and will be instantly recalled when pressed. To store such a page number, the TV must be in LIST mode, and the programme position must be from 1 – 10.

Press the BLUE key, select the page number, then press LIST STORE. The page number is now stored.


Press F.P. to recall this page number.

Note : Depending on the transmission sequence, when the F.P. key is pressed, the contents of the favourite page may take some time to appear. Only the page number is stored, not it's contents.



Teletext Operation

Reset




Press in FASTEXT mode to reset to the initial index page.
Press in LIST mode to reset to the RED coloured page.

Index



Press in FASTEXT mode to return to the main Index page.
Depending on the way information is transmitted, this may have to be pressed more than once to return to the main index page.

Display Cancel




Press to view the TV whilst searching for a Teletext page. When the page is found, the screen will display the FND symbol at the top left.

Press TV / TXT twice to view the page.

Press TV / TXT again to return to normal TV. operation.

Note : It is not possible to change the programme position when in News flash or Update mode.

News Flash




Press when a news flash page has been selected to view the TV. When an update of the news flash is received, it will be superimposed over the TV. picture.

Press again to remove updated news.

Press TV / TXT to return to normal TV. operation.

Update



Press to see the update of information on certain pages.

When an update is received, the UPD symbol will be displayed at the top left of the screen.


Press TV / TXT twice to view the page.

Press TV / TXT again to return to normal TV. operation.


Teletext Operation

Sub Coded Page Access


When teletext information exceeds more than one page, it may take some time for the automatic changing of the sub pages to reach the sub page you require. It is possible to enter your required sub page and continue watching the normal programme until the correct sub page is found.




Select the required page number using keys 0 – 9.



Press TIME TEXT, T**** will be displayed (top left of screen). Enter desired sub page number before the T**** disappears. To select page 6 enter 0, 0, 0 and 6. If in LIST mode, a 'T' will appear in the current box at the bottom.



Press DISPLAY CANCEL to view a normal TV programme. The FND symbol will be displayed when the page is available.




Press TV / TXT twice to view the page. To clear the page perform one of the following :

1. Press RESET to return to the main index page.
2. Select a new page number.
3. Press TV/TXT to return to normal TV operation.

Note :

It is not possible to select another programme during Sub Coded Page Access.




VCR Operation

VCR Operation


The Remote Control is capable of operating some functions of selected Panasonic VCR's, please consult your dealer for details. Some VCR's have different functions, so to ensure compatibility, please refer to the VCR instruction book.

Standby




Press to switch the VCR to standby mode. Press again to switch back on.

Fast Forward / Cue




Press to fast forward the tape. In Play mode, press to view the picture rapidly forward.

Play




Press to playback the tape.

Rewind / Review




Press to rewind the tape. In Play mode, press to view the picture in reverse rapidly.

Stop



Press to stop the tape.

Pause / Still



Press in playback mode, the picture will pause.

VCR Operation

Still Advance

7



While in PAUSE / STILL mode, press to advance the picture one frame at a time.

Programme Up / Down


8



Press to increase or decrease the VCR programme position by one.

Record

9



Press these together to record.

Audio Out Selection

10


AUDIO OUT



If a Stereo Hi-Fi VCR is connected to this TV, press this key to select the sound output required.

Note :

If any difficulty is encountered when using this remote control with Panasonic video tape recorders please check the operation of the video recorder with the operating switch set at position one and again with the switch set at position two.




Audio / Video (AV) Connections


Via the 21 Pin (SCART) terminals

Notes :


1. To connect a VHS VCR use the AV1 21 pin terminal.
2. To connect an S-Video VCR use the AV2 S-Video 21 pin terminal.



Via the AV3 4 Pin S-Video and RCA Audio terminals




Via the rear AV2 RCA Audio Out terminals




Audio / Video (AV) Connections

Via the front AV3 Video and Audio (RCA) terminals



Headphones Terminal










Notes :

1. Cables shown are not supplied with this T.V. set.
2. Do not connect a computer with TTL output (5V) to this set.
3. The AV1 and AV2 21 pin terminals can also be used as Outputs to Audio / Video Equipment.
4. For headphones operation, 2 channel stereo must be selected, the internal and external speakers will be automatically disconnected while the headphones are connected.

Trouble-shooting

Before calling for service, determine the symptoms and make a few simple checks as shown below.

Symptoms		Checks
Picture	Sound	
 Snowy Picture	 Noisy Sound	Aerial location, direction or connection
 Multiple Images	 Normal Sound	Aerial location, direction or connection
 Interference	 Noisy Sound	Electrical appliances Cars / Motorcycles Fluorescent lights
 Normal Picture	 No Sound	Volume level, Sound muted
 No Picture	 No Sound	Not plugged into A.C. outlet Not switched on Picture / Sound controls set at minimum levels Check if in standby mode
 No Colour	 Normal Sound	Colour controls set at minimum levels
 Poor or Distorted Picture	 Weak or No Sound	Retune Channel(s)
 Coloured Patches	 Normal Sound	Magnetic Interference from unshielded equipment Receiver moved while switched ON, switch TV off for 30 minutes.

Specifications

Power Source	220V – 240V 50Hz A.C.
Power Consumption TX-28X1DP TX-25X1DP	143 W 138 W
Picture Tube TX-28X1DP TX-25X1DP	66cm V FST 110° 59cm V FST 110°
Audio Output	6 x 10W Music
Dimensions TX-28X1DP TX-25X1DP	H W D 551 x 686 x 489mm 507 x 635 x 467mm
Weight TX-28X1DP TX-25X1DP	38.5 kg 33 kg

Receiving Systems	PAL – I (UHF) PAL – 60
Connections	
Aerial	(Rear of T.V.) (UHF Only)
Headphones	(Front of T.V.)
AV1	21 pin terminal (Audio / Video in / out) (RGB in)
AV2	21 pin terminal (Audio / Video in / out) (S-Video in) 2 x RCA Audio out
AV3	S-Video 4 pin terminal 2 x RCA Audio in 1 x RCA Video in
External Speakers	4 x 8Ω speakers Right front Left front Right rear surround Left rear surround

Note : Specifications are subject to change without notice. Weight and dimensions shown are approximate.

General Information

Service

Before requesting service, please refer to the trouble—shooting guide on page 26 to determine the symptoms. To obtain service please contact your local Panasonic dealer quoting the model number and serial number (both are located at the rear of the TV).



TV. Games / Home Computers

Extended use of TV games or home computers with any television set can cause a permanent 'shadow' on the screen. This type of irreversible picture tube damage, can be limited by observing the following points :

1. Reduce the brightness and contrast levels to a minimum viewing level.
2. Do not operate the television set for a continuous period of time while using TV games or home computers.

This type of picture tube damage, is not an operating defect, and as such is not covered by the Panasonic warranty.

Audio / Video 21 pin and S-Video 4 pin terminal specifications

Socket: Earth 21 — CVBS out (video) 19 — CVBS earth 17 — Red in 15 — Red earth 13 — Green in 11 — Green earth 9 — Blue in 7 — Blue earth 5 — Audio out (L) 3 — Audio out (R) 1 —		20 — CVBS in (video) 18 — RGB status earth 16 — Status RGB 14 — Ground 12 — 10 — 8 — Status CVBS 6 — Audio in (L) 4 — Audio earth 2 — Audio in (R)	Note : The AV2 21 pin terminal has the following differences from the AV1 21 pin terminal :— PIN 7 — No connection PIN 11 — No connection PIN 15 — S.C — in PIN 16 — No connection PIN 20 — CVBS in (S-Y in)	 Chrominance in — Chrominance earth — Luminance in — Luminance earth —
---	---	--	---	---

Note : Pins 15 and 20 of the AV2 21 pin terminal are dependant on AV2 S-Video / VIDEO switching.

"Dolby", "Pro Logic" and the  symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories Licensing Corporation.

Notes

[illegible]